

TABELA DOBORU KOŃCÓWEK DRAŻKÓW DO ATV / UTV

aktualizacja 04.02.2014

www.moto-maniak.eu

ARCTIC CAT

Model	LEWY GWINT KOŃCÓWKA		PRAWY GWINT KOŃCÓWKA	
	WEW EPI	X-ATV	ZEWN EPI	X-ATV
250 2x4 06-08	WE315021	41-1021	WE315025	41-1025
250 2x4 00-04	WE315017	41-1019	WE311023	41-1023
250 4x4 01-05	WE315017	41-1019	WE311023	41-1023
250 DVX 2x4 06-08	WE315021	41-1021	WE315025	41-1025
300 2x4 00-04	WE315017	41-1019	WE311023	41-1023
300 4x4 00-05	WE315017	41-1019	WE311023	41-1023
375 2x4 / 4x4 w/AT 02	WE315017	41-1019	WE311023	41-1023
400 2x4 w/MT 01	WE315017	41-1019	WE311023	41-1023
400 2x4 00-01	WE315017	41-1019	WE311023	41-1023
400 4x4 00	WE315017	41-1019	WE311023	41-1023
400 4x4 w/AT 03-04	WE315017	41-1019	WE311023	41-1023
400 4x4 w/MT 01-04	WE315017	41-1019	WE311023	41-1023
400 FIS 2x4 w/AT or w/MT 03-04	WE315017	41-1019	WE311023	41-1023
400 FIS 4x4 w/AT or w/MT 03-08	WE315017	41-1019	WE311023	41-1023
400 FIS 4x4 02	WE315017	41-1019	WE311023	41-1023
400 DVX 04-07	WE315021	41-1021	WE315025	41-1025
400 TBX 4x4 04/06	WE315017	41-1019	WE311023	41-1023
400 VP 4x4 06	WE315017	41-1019	WE311023	41-1023
500 4x4 w/AT 00-02	WE315017	41-1019	WE311023	41-1023
500 4x4 w/MT 01	WE315017	41-1019	WE311023	41-1023
500 FIS 4x4 w/AT or w/MT 02-08	WE315017	41-1019	WE311023	41-1023
500 FIS TBX/TRV 4x4 05-06	WE315017	41-1019	WE311023	41-1023
500 TBX 4x4 04	WE315017	41-1019	WE311023	41-1023
500 TBX 4x4 w/AT 02-03	WE315017	41-1019	WE311023	41-1023
500 TRV 4x4 03-04	WE315017	41-1019	WE311023	41-1023
650 H1 4x4 05-07	WE315017	41-1019	WE311023	41-1023
650 V2 4x4 04-06	WE315017	41-1019	WE311023	41-1023
700 Diesel 4x4 07-08	WE315017	41-1019	WE311023	41-1023
700 EFI 4x4 07-08	WE315017	41-1019	WE311023	41-1023



TABELA DOBORU KOŃCÓWEK DRAŻKÓW DO ATV / UTV

aktualizacja 04.02.2014

www.moto-maniak.eu

CAN-AM

Model	LEWY GWINT KOŃCÓWKA		PRAWY GWINT KOŃCÓWKA	
	WEW EPI	X-ATV	ZEWN EPI	X-ATV
330 Outlander 04-05	WE311011	41-1011	WE315015	41-1015
400 Outlander 03-13	WE311011	41-1011	WE315015	41-1015
500 Outlander 4x4 13	WE315037	41-1052	WE315036	41-1011
500 Outlander 07-12	WE311011	41-1011	WE315015	41-1015
500 Renegade 4x4 13	WE315037	41-1052	WE315036	41-1011
500 Renegade 08-12	WE311011	41-1011	WE315015	41-1015
500 Traxter 4x4 99-05	WE315037	41-1052	WE315036	41-1011
650 Outlander 4x4 13	WE315037	41-1052	WE315036	41-1011
650 Outlander 07-12	WE311011	41-1011	WE315015	41-1015
650 Quest 4x4 02-04	WE315037	41-1052	WE315036	41-1011
650 Traxter 4x4 04-05	WE315037	41-1052	WE315036	41-1011
800 Outlander 4x4 13	WE315037	41-1052	WE315036	41-1011
800 Outlander 4x4 12	WE315037	41-1052	WE315036	41-1011
800 Outlander 06-11	WE311011	41-1011	WE315015	41-1015
800 Outlander Xmr 4x4 12	WE311011	41-1011	WE315015	41-1015
800 Renegade 4x4 12-13	WE315037	41-1052	WE315036	41-1011
800 Renegade 07-11	WE311011	41-1011	WE315015	41-1015
800 Renegade Xxc 4x4 12	WE311011	41-1011	WE315015	41-1015
1000 Outlander 4x4 13	WE315037	41-1052	WE315036	41-1011
1000 Outlander 4x4 12	WE311011	41-1011	WE315015	41-1015
1000 Renegade 4x4 13	WE315037	41-1052	WE315036	41-1011
1000 Renegade 4x4 12	WE311011	41-1011	WE315015	41-1015



TABELA DOBORU KOŃCÓWEK DRAŻKÓW DO ATV / UTV

aktualizacja 04.02.2014

www.moto-maniak.eu

HONDA

Model	LEWY GWINT KOŃCÓWKA		PRAWY GWINT KOŃCÓWKA	
	WEW	X-ATV	ZEWN	X-ATV
TRX 200 96-97	WE315010	41-1010	WE315015	41-1015
TRX 200 90-91	WE315010	41-1010	WE315015	41-1015
TRX 200 D 90-97	WE315010	41-1010	WE315015	41-1015
TRX 250 EX Sportrax 01-08	WE315010	41-1010	WE315015	41-1015
TRX 250 R 86-89	WE315008	41-1008	WE315013	41-1013
TRX 250 Recon 97-07	WE315010	41-1010	WE315015	41-1015
TRX 250 X 87-92	WE315008	41-1008	WE315013	41-1013
TRX 300 EX 93-08	WE315008	41-1008	WE315013	41-1013
TRX 300 / FW Fourtrax 4x4 88-00	WE315010	41-1010	WE315015	41-1015
TRX 350 FE Fourtrax Rancher 00-03	WE315010	41-1010	WE315015	41-1015
TRX 350 FM / TE / TM Fourtrax Rancher 00-06	WE315010	41-1010	WE315015	41-1015
TRX 400 EX 99-07	WE315008	41-1008	WE315013	41-1013
TRX 400 FA / FGA Fourtrax Rancher 4x4 04-06	WE315010	41-1010	WE315015	41-1015
TRX 400 FM Fourtrax Foreman 4x4 02	WE315010	41-1010	WE315015	41-1015
TRX 400 FW Fourtrax Foreman 4x4 03	WE315010	41-1010	WE315015	41-1015
TRX 400 FW Fourtrax Foreman 4x4 95-01	WE315010	41-1010	WE315015	41-1015
TRX 420 FE / FM / TE / TM 08	WE315010	41-1010	WE315015	41-1015
TRX 450 ER 06-08	WE315008	41-1008	WE315013	41-1013
TRX 450 R 04-08	WE315008	41-1008	WE315013	41-1013
TRX 450 FE / FM 02-04	WE315010	41-1010	WE315015	41-1015
TRX 450 S / ES 98-01	WE315010	41-1010	WE315015	41-1015
TRX 500 FA 01-08	WE315010	41-1010	WE315015	41-1015
TRX 500 FE / FM 05-08	WE315010	41-1010	WE315015	41-1015
TRX 500 FGA 04-08	WE315010	41-1010	WE315015	41-1015
TRX 500 FPE / FPM 08	WE315010	41-1010	WE315015	41-1015
TRX 500 TM 05-06	WE315010	41-1010	WE315015	41-1015
TRX 650 Rincon 03-05	WE315010	41-1010	WE315015	41-1015
TRX 680 Rincon 06-08	WE315010	41-1010	WE315015	41-1015



TABELA DOBORU KOŃCÓWEK DRAŻKÓW DO ATV / UTV

aktualizacja 04.02.2014

www.moto-maniak.eu

KAWASAKI

Model	LEWY GWINT KOŃCÓWKA WEW		PRAWY GWINT KOŃCÓWKA ZEWN	
	EPI	X-ATV	EPI	X-ATV
110 87-88	WE315017	41-1019	WE315022	-
185 Bayou 85-88	WE315017	41-1019	WE315022	-
220 Bayou 88-02	WE315017	41-1019	WE315022	-
250 Bayou 03-08	WE315017	41-1019	WE315022	-
250 Mojave 87-04	WE315017	41-1019	WE315022	-
250 Tecate 87-88	WE315017	41-1019	WE315022	-
300 Bayou 86-04	WE315017	41-1019	WE315022	-
300 Lakota 95-03	WE315017	41-1019	WE315022	-
300 Prairie 01-02	WE311018	41-1018	WE315022	-
300 Prairie 99-00	WE315017	41-1019	WE315022	-
360 Prairie 03-08	WE311011	41-1011	WE315015	41-1015
400 Bayou 93-99	WE315017	41-1019	WE315022	-
400 KFX 04-06	WE315021	41-1021	WE315025	41-1025
400 KFX 03	WE315017	41-1019	WE315022	-
400 Prairie 01-02	WE311018	41-1018	WE315022	-
400 Prairie 97-00	WE315017	41-1019	WE315022	-
KFX 450 R 08-11	WE311045	41-1045	WE311046	41-1046
650 Brute Force 05-12	WE311018	41-1018	WE311023	41-1023
650I Brute Force 06-13	WE315008	41-1008	WE315013	41-1013
650 Prairie 02-03	WE311018	41-1018	WE311023	41-1023
KFX 700 04-08	WE315027	41-1039	WE315028	41-1040
700 Prairie 04-06	WE311018	41-1018	WE311023	41-1023
750 Brute Force 05-13	WE315008	41-1008	WE315013	41-1013
750 Brute Force EPS 12-13	WE315008	41-1008	WE315013	41-1013



TABELA DOBORU KOŃCÓWEK DRAŻKÓW DO ATV / UTV

www.moto-maniak.eu

aktualizacja 04.02.2014

POLARIS

Model	LEWY GWINT KOŃCÓWKA		PRAWY GWINT KOŃCÓWKA	
	ZEWN EPI	X-ATV	WEW EPI	X-ATV
250 Trail Blazer 2x4 97-06	WE311138	41-1032	WE311139	41-1031
250 Xplorer 4x4 00-02	WE311138	41-1032	WE311139	41-1031
300 Xplorer 4x4 98-99	WE311138	41-1032	WE311139	41-1031
300 Xpress 2x4 98-99	WE311138	41-1032	WE311139	41-1031
325 Magnum 2x4 / 4x4 00-02	WE311138	41-1032	WE311139	41-1031
325 Trail Boss 2x4 00-02	WE311138	41-1032	WE311139	41-1031
325 Xpedition 4x4 00-02	WE311138	41-1032	WE311139	41-1031
330 ATP 4x4 04-05	WE311138	41-1032	WE311139	41-1031
330 Magnum 2x4 03-05	WE311138	41-1032	WE311139	41-1031
330 Magnum 4x4 03-06	WE311138	41-1032	WE311139	41-1031
330 Trail Boss 2x4 03-07	WE311138	41-1032	WE311139	41-1031
330 Trail Boss 4x4 03	WE311138	41-1032	WE311139	41-1031
335 Sportsman 4x4 99-00	WE311138	41-1032	WE311139	41-1031
400 Scrambler 2x4 00-02	WE311138	41-1032	WE311139	41-1031
400 Scrambler 4x4 97-00 / 02	WE311138	41-1032	WE311139	41-1031
400 Sport 2x4 97-99	WE311138	41-1032	WE311139	41-1031
400 Sportsman 4x4 01-05	WE311138	41-1032	WE311139	41-1031
400 Trail Blazer 2x4 03	WE311138	41-1032	WE311139	41-1031
400 Xplorer 4x4 98-02	WE311138	41-1032	WE311139	41-1031
425 Magnum 2x4 98	WE311138	41-1032	WE311139	41-1031
425 Magnum 4x4 98	WE311138	41-1032	WE311139	41-1031
425 Xpedition 4x4 00-02	WE311138	41-1032	WE311139	41-1031
450 Sportsman 4x4 06-07	WE311138	41-1032	WE311139	41-1031
500 ATP 4x4 04-05	WE311138	41-1032	WE311139	41-1031
500 Big Boss 6x6 98-99	WE311138	41-1032	WE311139	41-1031
500 Magnum RMK 4x4 02	WE311138	41-1032	WE311139	41-1031
500 Magnum 4x4 99-02	WE311138	41-1032	WE311139	41-1031
500 Predator 2x4 03-06	WE311112	41-1042	WE311113	41-1041
500 Ranger 2x4 / 4x4 04-07	WE311138	41-1032	-	-
500 Ranger EFI 4x4 06-07	WE311138	41-1032	-	-
500 Ranger 6x6 04-05	WE311138	41-1032	-	-
500 Scrambler 2x4 01-02	WE311138	41-1032	WE311139	41-1031
500 Scrambler 4x4 97-07	WE311138	41-1032	WE311139	41-1031
500 Sportsman EFI 4x4 06-08	WE311138	41-1032	WE311139	41-1031
500 Sportsman EFI X2 4x4 07-08	WE311138	41-1032	WE311139	41-1031
500 Sportsman HO 4x4 01-08	WE311138	41-1032	WE311139	41-1031
500 Sportsman X2 4x4 06	WE311138	41-1032	WE311139	41-1031
500 Sportsman 4x4 98-00	WE311138	41-1032	WE311139	41-1031
500 Sportsman 6x6 00-07	WE311138	41-1032	WE311139	41-1031
600 Sportsman 4x4 03-05	WE311138	41-1032	WE311139	41-1031
700 MV7 4x4 05	WE311138	41-1032	WE311139	41-1031
700 Ranger XP 4x4 05-07	WE311138	41-1032	-	-
700 Ranger EFI 6x6 06-07	WE311138	41-1032	-	-
700 Sportsman 4x4 02-07	WE311138	41-1032	WE311139	41-1031
700 Sportsman EFI 4x4 04-07	WE311138	41-1032	WE311139	41-1031
700 Sportsman EFI X2 4x4 08	WE311138	41-1032	WE311139	41-1031
800 Sportsman EFI HO 4x4 08	WE311138	41-1032	WE311139	41-1031
800 Sportsman EFI 4x4 05-07	WE311138	41-1032	WE311139	41-1031
800 Sportsman EFI X2 4x4 07	WE311138	41-1032	WE311139	41-1031
Diesel 4x4 99 / 01	WE311138	41-1032	WE311139	41-1031
Ranger TM 2x4 04-06	WE311138	41-1032	-	-
850 Sportsman XP 4x4 10-12	WE315022	-	WE311018	41-1018
850 Sportsman XP EPS 4x4 10-12	WE315032	41-1032	WE315031	41-1031
850 Sportsman XP EPS 4x4 09	WE315032	41-1032	WE315031	41-1031

TABELA DOBORU KOŃCÓWEK DRAŻKÓW DO ATV / UTV

aktualizacja 04.02.2014

www.moto-maniak.eu

SUZUKI

Model	LEWY GWINT KOŃCÓWKA WEW		PRAWY GWINT KOŃCÓWKA ZEWN	
	EPI	X-ATV	EPI	X-ATV
LT-F 250 Ozark 04-07	WE315021	41-1021	WE315025	41-1025
LT-F 250 Ozark 03	WE315017	41-1019	WE315022	-
LT-Z 250 04-07	WE315021	41-1021	WE315025	41-1025
LT-A 400F Eiger 4WD 05-07	WE315021	41-1021	WE315025	41-1025
LT-F 400F Eiger 4WD 05-07	WE315021	41-1021	WE315025	41-1025
LT-Z 400 04-07	WE315021	41-1021	WE315025	41-1025
LT-Z 400 03	WE315017	41-1019	WE315022	-
LT-R 450 06-07	WE311046	41-1046	WE311045	41-1045
LT-A 500F Vinson 04-07	WE315021	41-1021	WE315025	41-1025
LT-A 500F Vinson 03	WE315017	41-1019	WE315022	-
LT-F 500F Vinson 04-07	WE315021	41-1021	WE315025	41-1025
LT-F 500F Vinson 03	WE315017	41-1019	WE315022	-
LT-A 700X 05-07	WE315030	41-1048	WE315029	41-1047
LT-V 700F 04-06	WE311018	41-1018	WE311023	41-1023
LT-A 750X 07-12	WE315030	41-1048	WE315029	41-1047
LT-A 750X EPS	WE311046	41-1046	WE311045	41-1045



TABELA DOBORU KOŃCÓWEK DRAŻKÓW DO ATV / UTV

www.moto-maniak.eu

aktualizacja 04.02.2014

YAMAHA

Model	LEWY GWINT KOŃCÓWKA ZEWN		PRAWY GWINT KOŃCÓWKA WEW	
	EPI	X-ATV	EPI	X-ATV
50 Raptor 04-08	WE311016	-	WE311023	41-1023
80 YFM 85-88	WE311016	-	WE311023	41-1023
80 Badger 92-01	WE311016	-	WE311023	41-1023
80 Grizzly 05-08	WE311016	-	WE311023	41-1023
80 Raptor 02-08	WE311016	-	WE311023	41-1023
100 YFM 87-91	WE311016	-	WE311023	41-1023
125 Grizzly 04-08	WE315021	41-1021	WE315025	41-1025
125 YFA1 91-04	WE315021	41-1021	WE315025	41-1025
200 Blaster 88-06	WE315021	41-1021	WE315025	41-1025
200 Moto-4 86-89	WE315021	41-1021	WE315025	41-1025
225 Moto-4 86-88	WE315021	41-1021	WE315025	41-1025
250 Beartracker 99-04	WE311009	41-1009	WE311014	41-1014
250 Big Bear 07-08	WE311009	41-1009	WE311014	41-1014
250 Bruin 05-06	WE311009	41-1009	WE311014	41-1014
250 Moto-4 89-91	WE315021	41-1021	WE315025	41-1025
250 Raptor 08	WE315021	41-1021	WE315025	41-1025
250 Timberwolf 92-00	WE315021	41-1021	WE315025	41-1025
350 Banshee 87-06	WE315021	41-1021	WE315025	41-1025
350 Big Bear 87-99	WE315021	41-1021	WE315025	41-1025
350 Bruin 2x4/4x4 04-06	WE311009	41-1009	WE311014	41-1014
350 Grizzly 2x4/4x4 07-08	WE311009	41-1009	WE311014	41-1014
350 Moto-4 87-95	WE315021	41-1021	WE315025	41-1025
350 Raptor 04-08	WE315021	41-1021	WE315025	41-1025
350 Wolverine 95-05	WE315021	41-1021	WE315025	41-1025
350 Warrior 87-04	WE315021	41-1021	WE315025	41-1025
400 Big Bear 2x4 00-04	WE311009	41-1009	WE311014	41-1014
400 Big Bear 4x4 00-06	WE311009	41-1009	WE311014	41-1014
400 Kodiak 2x4 03-04	WE311009	41-1009	WE311014	41-1014
400 Kodiak 2x4 00-01	WE315021	41-1021	WE315025	41-1025
400 Kodiak 4x4 03-04	WE311009	41-1009	WE311014	41-1014
400 Kodiak 4x4 93-02	WE315021	41-1021	WE315025	41-1025
450 Kodiak 03-06	WE311009	41-1009	WE311014	41-1014
450 Wolverine 06-08	WE311009	41-1009	WE311014	41-1014
450 YFZ 06-08	WE311046	41-1046	WE311045	41-1045
450 YFZ 04-05	WE315021	41-1021	WE315025	41-1025
600 Grizzly 98-01	WE315021	41-1021	WE315025	41-1025
660 Grizzly 02-08	WE315021	41-1021	WE315025	41-1025
660 Raptor 01-05	WE315021	41-1021	WE315025	41-1025
700 Grizzly 07-08	WE315021	41-1021	WE315025	41-1025
700 Grizzly w/power steering 08	WE315021	41-1021	WE315025	41-1025
700 Raptor 06-08	WE311046	41-1046	WE311045	41-1045

